1849163
GALLERY HALL TABLE

Parts and Hardware List

A.	Table Top	1 pc
B.	Legs	4 pcs
C.	Allen Head Bolts	8 pcs
D.	Lock Washers	8 pcs
E.	Flat Washers	8 pcs
F.	Allen Head Wrench	1 pc

* Please make sure that you have all the parts and hardware indicated above before you begin assembly of this item.
* Use the hardware illustrations to determine correct piece and size.
* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
* This table may require periodic tightening.

Hardware Illustrations



C. Allen Head Bolts



E. Flat Washer



D. Lock Washer

1849163
GALLERY HALL TABLE

Attach Legs

Parts required

A.	Table Top	1 pc	D.	Lock Washers	8 pcs
B.	Legs	4 pcs	E.	Flat Washers	8 pcs
C.	Allen Head Bolts	8 pcs	F.	Allen Head Wrench	1 pc

1. **Attach Legs (B)**. Place the Table Top (A) upside down on a soft surface. Align the pre-drilled holes in the Legs (B) with the pre-drilled holes in the corner blocks of the Top Panel (A). Secure in place with the Allen Head Bolts (C), Lock Washers (D), and Flat Washers (E), using the Allen Head Wrench (F). See Illustration #1.
   Repeat for the other legs.



Illustration # 1